



## Re-engineered light truck ball joint for Mercedes Sprinter and VW LT & Crafter



	SIDEM	APPLICATION	N° OE
50080	ball joint	Mercedes Sprinter 901/2/3/4/5 VW LT 28II & LT 35II (2DM)	901 333 12 27 2D0 407 361 A
50083	ball joint	Mercedes Sprinter 906 VW Crafter (2E)	Part of Part of

The rubber boot is re-engineered

- to ensure a better sealing of the inside.
- it is made thicker, to better resist the impact of particles that come from the road.

The endurance of this part is improved

- the plastic bearing is re-engineered from scratch to withstand the loads what this type of vehicles have to endure even better than before.

And last but not least ,the part resembles optical even more to the OE-part than before.

Sidem part



OE part